Accessories and control

Controls and room thermostats



Remote controller with Wi-Fi adapter (required for stand-alone outdoor units). M Series. Includes 10 m extension cable.

CZ-RTW2TAW1C



Optional remote controller for 2 zone control. K and L Series.

CZ-RTW1

Optional remote controller for 2 zone control. M Series.

CZ-RTW2

Remote control compartment cover for K, L and M Series indoor units.

PAW-A2W-COV-KL



Wired LCD room thermostat with weekly timer.

PAW-A2W-RTWIRED



Wireless LCD room thermostat with weekly timer.

PAW-A2W-RTWIRELESS

Cascade solutions



Cascade manager for Aquarea Heat Pumps. Cascade up to 10 Aquarea Heat Pumps.

PAW-A2W-CMH-3



Aquarea Cascade Edge (manager) for Aquarea Heat Pumps with P-Smart Edge control and monitoring software. Cascade up to 4 units.

PAW-A2W-CME4

Aquarea Cascade Edge (manager) for Aquarea Heat Pumps with P-Smart Edge control and monitoring software. Cascade up to 10 units.

PAW-A2W-CME10

PCBs for additional functions



PCB for advanced functions. H and J Series.

CZ-NS4P

PCB for advanced functions. K and L Series.

CZ-NS5P

PCB for advanced functions. M Series All in One and Bi-bloc.

CZ-NS6P

PCB for advanced functions. M Series control module.

CZ-NS7P

Indoor unit accessories

Wall bracket to mount the All in One 120 L on the wall.

* Check availability.

CZ-NW1

Outdoor unit accessories



Base pan heater for Bi-bloc 3 and 5 kW (except L Series) and K Series 7 and 9 kW (1 fan model).

CZ-NE2P

Base pan heater. L Series 5, 7 and 9 kW and M Series.


CZ-NE4P

Base pan heater. H and J Series and K Series 9 kW (2 fans model), 12 and 16 kW.

CZ-NE3P

Base pan heater. M Series 20, 25, 30 kW.

CZ-NE5P



Outdoor base ground support for noise and vibration absorption.
Dimension (H x W x D):
600 x 95 x 130 mm
Safe working load: 500 kg

PAW-GRDBSE20



Black ground stand for outdoor unit with 940 mm wide condenser water tray.

———

PAW-GRDSTD940



Black ground stand for outdoor unit with 1100 mm wide condenser water tray.

———

PAW-GRDSTD1100

Electrical heater foil for the ground stand with 940 mm wide condenser water tray.

———


PAW-GRDSTDHTR940

Electrical heater foil for the ground stand with 1100 mm wide condenser water tray.

———

PAW-GRDSTDHTR1100

Hydraulic accessories



3 way valve kit to fit inside the hydrokit. H and J Series.

———

CZ-NV1

3 way valve kit to fit inside the hydrokit. K and L Series.

———

CZ-NV2

3 way valve kit to fit inside the hydrokit. M Series.

———

CZ-NV3



3 way valve for DHW tanks.

———

PAW-3WYVLV-HW



1 antifreeze valve. It is required to order 2 valves per system. For 9, 12 and 16 kW.

———

PAW-A2W-AFVLV-1

1 antifreeze valve 1 1/2". It is required to order 2 valves per system. For 20, 25 and 30 kW.

———

PAW-A2W-AFVLV-112



Optional magnet for the water filter in H Series models.

———

PAW-A2W-MGTFILTER

Connectivity



Optional Wi-Fi or WLAN adapter for smart control via Panasonic Comfort Cloud and/or remote maintenance via Aquarea Service Cloud.

———

CZ-TAW1C

10 m extension cable for CZ-TAW1C.

———

CZ-TAW1-CBL

Aquarea Home Network Hub.

———

PCZ-ESW737



External meter gateway for K Series onwards.

———

PAW-A2W-EXTMETER



Modbus PCB for Big Aquarea T-CAP M Series (installed inside the WH-CME8L).

———

CZ-NSMB



Modbus interface for H Series onwards (Airzone).

———

PAW-AZAW-MBS-M



Modbus interface (Intesis). H and J Series.

———

PAW-AW-MBS-H



KNX interface for H Series onwards (Airzone).

———

PAW-AZAW-KNX-1



KNX interface for H Series onwards (Intesis).

———

PAW-AW-KNX-H

Sensors for Aquarea H Series onwards



Outdoor ambient sensor.

———

PAW-A2W-TSOD

Zone room sensor.

———

PAW-A2W-TSRT



Zone water sensor.

———

PAW-A2W-TSHC



Solar sensor.

———

PAW-A2W-TSSO



Buffer tank sensor (for H and J Series, PAW-A2W-TSHC required if optional PCB is used.

———

PAW-A2W-TSBU

In-line heater sensor for the control module M Series.

———

PAW-A2W-TSBH

tado° room control and smart energy management

tado° Room control sets with Heat Pump Optimizer X



Set of tado° Heat Pump Optimizer X and 1x Smart Radiator Thermostat X.

———

KIT-TSRTXHP0XE



Set of tado° Heat Pump Optimizer X and 4x tado° Smart Radiator Thermostat X.

———

KIT-TSRTX4HP0XE



Set of tado° Heat Pump Optimizer X and 1x Smart Thermostat X.

———

KIT-TSTXHP0XE



Set of tado° Heat Pump Optimizer X and 1x Smart Thermostat X and 2x Smart Radiator Thermostat X.

———

KIT-TSTXSRTX2HP0XE

tado° Room control sets with Bridge X



tado° Smart Radiator Thermostat X with Bridge X.

———

PAW-TSRTXB



tado° Smart Thermostat X with Bridge X.

———

PAW-TSTXB



Set of 1x Smart Thermostat X, 2x Smart Radiator Thermostat X and 1x Bridge X.

———

PAW-TSTXSRTX2B

tado° X devices



tado° Heat Pump Optimizer X (with Europlug).

———

PAW-THP0XE



tado° Smart Thermostat X.

———

PAW-TSTX

tado° Wireless Temperature Sensor X.

———

PAW-TWTSX



tado° Smart Radiator Thermostat X.

———

PAW-TSRTX

4x tado° Smart Radiator Thermostat X.

———

PAW-TSRTX4



tado° Bridge X.

———

PAW-TBX